
4 bits used from DSP card Bandswitch connector P13:

2 LS bits control the Multi-Rx card filters2 MS bits control the Multi-Tx card filtersBits change at frequencies indicated here



Circled bit pairs are the ones that change as frequency increases